

Rubber Paver Tiles: Installation Instructions



1. Thoroughly clean the surface where the pavers are to be installed. Allow to dry completely. Make sure that both paver and surface have no moisture on them for best adhesion.
2. Place Rubber Paver on surface to assure you have the proper amount and that you like the overall design.
3. To achieve the best results, snap chalk lines as a guide and pavers will be straight during installation.
4. Begin installation in a corner or against a wall and work in small section.
5. Apply a polyurethane adhesive such as Gorilla Glue to the bottom of the paver and place on surface.
6. Gently tap tiles into place with a rubber mallet for adhesion.
7. Continue laying full pavers in place until complete.
8. For any pavers that require cutting, use a razor knife, cutting the paver in a series of scores to acquire a clean edge.
9. Allow area to dry for a minimum of 24 hours before use.
10. After installation some natural weathering of pavers may occur.

Note: If attaching pavers to a wood surface you may also use a one-inch staple in place of polyurethane adhesive.